

accM400P



Sweet  
Dreams

## Cotton Candy maker

- Make fluffy cotton candy like at the funfair
- Includes measuring spoon & 10 wooden sticks to get started right away
- Easy to use: Let it heat up for 5 minutes, then add some fine household sugar to the center of the bowl and the spinning can begin!
- It stands firmly on the table thanks to the suction cups at the bottom
- Easy to clean after each use with a damp cloth



EN



VE / COLIS / MC : 4



500W, 220-240V ~ 50/60Hz



8 7121 8406 2492